

Prophet '08

Manual Addendum

The latest version of the Prophet '08 operating system adds four features that are not documented in the manual. All of them appear in the Global menu. (See page 7 of the Operation Manual for more information about the Global menu.)

ControlReset: Norm (default), PgCh – When set to Norm, the settings of MIDI controllers such as volume, brightness, or modulation will be carried over with program changes. When set to PgCh, MIDI controllers will be reset when programs are changed locally or via MIDI. The reset is equivalent to sending the Prophet the Reset All Controllers message (CC 121) via MIDI.

BalanceTweak: -7...7 – Adjusts the left/right balance of the audio outputs by approximately +/- 4 dB.

Audio Out: Stereo (default), Mono – Switching from Stereo to Mono globally defeats all of the parameters that affect panning (pan spread, modulation, etc.) and makes both the left and right outputs mono outputs.

MIDIParamLCD: On (default), Off – In edit mode, the display normally shows any received controller changes. When MIDIParamLCD is Off, only local edits are displayed.